

The TEKVOX 2 Button keypad allows for a simple and low cost method to power on and off the projector along with a source selection. Pressing the ON/OFF button when the projector is off, turns on the projector and flashes the button until the projector is on. Likewise, pressing the ON/OFF button when the projector is on, turns off the projector and flashes the button until the projector is on. The Up Down arrow button is used to toggle between two sources, typically VGA and Video. There is no feedback to the source button. The best wire to use is the WestPenn 25241B 4 conductor for the 2 Button keypad and the 24231 3 conductor for the occupancy sensor.

